




Rear Seat Belts

Replacement

CAUTION: Check the seat belts for damage and replace them if necessary. Be careful not to damage them during removal and installation.

1. Remove the rear seat (page 14-43).
2. Remove the quarter trim panel and side shelf (page 14-39).
3. Remove the upper anchor bolt and retractor bolt with a 17 mm socket or box-end wrench.



4. Remove the lower anchor bolt and center anchor bolt, then remove the rear seat belts.
5. Check that the retractor locking mechanism functions as described on page 14-46.
6. Install the seat belt in the reverse order of removal.

NOTE: Before attaching the quarter trim panel and rear seat, make sure there are no twists in the belts.