



Lighting System (Except KE model)

Component Location Index





Circuit Diagram




Lighting System (Except KE model)

Lighting/Turn Signal Switch Test

1. Remove the dashboard lower panel.
2. Remove the steering wheel.
3. Remove the steering column covers then disconnect the 7-P and 4-P connectors.
4. Check for continuity between the terminals in each position according to the tables.

LIGHTING/DIMMER/PASSING
TURN SIGNAL SWITCH



Lighting/Dimmer/Passing Switch

Terminal		D	E	F	G	H	I
Lighting switch	OFF						
	☸	○	○				
	☹				○		○
Dimmer switch *	LOW			○	○		○
	HIGH				○	○	○
Passing switch	OFF						
	ON					○	○

* : With lighting switch position in (☹)

Turn Signal Switch

Terminal	A	B	C
R	○		○
NEUTRAL			
L	○	○	