





Damper Removal

1. Jack up the rear of car and support on safety stands in proper locations.
2. Remove the damper upper cover at the rear seat lining.
3. Remove the damper upper mounting base nuts.



REAR DAMPER ASSEMBLY



4. Remove the damper mounting bolt.
5. Remove the lower arm mounting bolt.
6. Lower the lower arm and remove the damper assembly.