





Trunk Lid Opener/Emblem

Trunk Lid Opener Replacement






- LHD:**
- To remove the opener cables, remove the following parts:
 - Left side door sill moldings, left and rear half of carpet.
 - Left quarter trim panel, and left trunk side panel.
 - Remove the screw and the release levers, then remove the opener cover. Remove the opener by removing the 2 bolts (page 14-57)
 - Remove the fuel filler lid latch by turning it 90° (page 14-57).
 - Remove the rear panel garnish.
 - Remove the bolt, then remove the trunk lid lock cylinder.
 - Remove the 3 bolts, then remove the trunk lid latch.
 - Disconnect the opener cable, connector and lock rod.



- To install, reverse the removal procedure. Check that the trunk lid and fuel filler lid opener cables are routed and connected properly.

Emblem Installation

Attachment Points:



NOTE: Before sticking, clean the body bonding surface with a sponge dampened in alcohol.