

Symbol Marks

The following symbols stand for:

 :Apply engine oil.

 :Apply brake fluid.

 :Apply grease.

 :Apply Automatic Transmission Fluid.

 : Apply Power Steering Fluid.

 :Apply or check vacuum.

①, ②, ③, :Sequence for removal or installation.
 ❶, ❷, ❸, :Sequence for removal or installation.

Abbreviation



4D	4-door Saloon
5D	5-door Saloon
A/C	Air Conditioner
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
B or BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	Electronic Control Unit
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L.	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV	Positive Crankcase Ventilation
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R.	Right
RHD	Right Hand Drive
SW	Switch
SOL. V	Solenoid Valve
TDC	Top Dead Center

	Parking
	Reverse
	Neutral
	Drive Position (1st~4th)
	Drive Position (1st~3rd)
	2nd speed