




# Power Distribution

## Circuit Identification






(cont'd)

# Power Distribution

## Circuit Identification (cont'd)

No.36(40A) FUSE  
From page 16-18





No.32(40A) FUSE  
From page 16-18

BRN/WHT

WHT/BLK

IGNITION SWITCH

BAT-B

IG2-B

ACC

BAT-A

ST

IG2-A

IG1

WHT

BRN/PUP

No.33(40A) FUSE  
From page 16-18

WHT

DASH FUSE BOX

No.17(10A)

No.2(10A)

No.18(10A)

No.15(20A)

No.13(15A)

No.14(10A)

No.1(10A)

Blower motor

Stereo radio / cassette player (ACC)  
Cigarette lighter relay

Starter solenoid

Starter signal

ALB relays  
Delay control unit  
Condenser fan-motor relay  
A/C compressor clutch relay  
A/C switch indicator light

Rear window defogger relay  
Power door mirrors

Radiator fan relay (with A/C)  
Radiator fan motor

Ignition coil

Wiper and washer motors

Power window relay  
to page 16-19

Sunroof relay

DIM-DIP control unit  
to page 16-20

Voltage regulator (IG)  
PGM-FI main relay  
PGM-FI ECU (IG1)  
EACV  
Emission control solenoid valves

Charge warning light

Integrated control unit (IG1)

Back-up lights

Turn signal lights  
Clock (IG1)  
Gauges and Warning lights  
Shift position indicator