



Fuel Tank

Replacement

⚠ WARNING Do not smoke while working on fuel system. Keep open flame away from area.

1. Block front wheels. Jack up up the rear of the car and support with jackstands.
2. Disconnect the fuel gauge sending unit connector.
3. Disconnect the hoses.

CAUTION: When disconnecting the hoses, slide back the clamps, then twist hoses as you pull, to avoid damaging them.

4. Place a jack, or other support, under the tank.
5. Remove the strap nuts and let the straps fall free.
6. Remove the fuel tank.

NOTE: The tank may stick on the undercoat applied to its mount. To remove, carefully pry it off the mount.

7. Install parts in the reverse order of removal.

