

Idle Control System

Fast Idle Control [1.6 l only]

Troubleshooting Flow Chart

Inspection of Fast Idle Control Solenoid Valve.

Warm up engine to normal operating temperature (cooling fan comes on).

Disconnect the upper vacuum hose from the fast idle control solenoid valve and connect a vacuum gauge to the valve.

