



# Rear Seats

## Disassembly

Disassemble in numbered sequence.

NOTE: Before tighten the seat back mounting bolts, adjust the seat back latch fit striker.

### REAR SEAT LATCH

Remove the trim panel turn over the trim cover and pad. Remove the bolts, then remove the seat latch.

Use TORX® T30  
6 x 1.0 mm  
10 N·m (1.0 kg-m,  
7 lb-ft)

