



Condenser




Replacement

1. Discharge the refrigerant.
2. Remove the bumper.
3. Remove the center stay bracket.




4. Disconnect the condenser pipe and discharge pipe from the condenser.

CAUTION: Cap the open fittings immediately to keep moisture and dirt out of system.



5. Remove the mounting bolts (2) and condenser.



Install in the reverse order of removal, charge the system (page 15-50) and test performance (page 15-56).