


Room Light

Test


1. Turn the light switch OFF.
2. Pry off the lens.
3. Remove the 2 nuts (with sunroof) or screw (without sunroof) and housing.
4. Disconnect the 3-p connector from the housing.
5. Remove the room light.





6. Check for continuity between the terminals in each switch position according to the table.

Terminal Position	A	B or B'	C		D
OFF			○	⊗	○
DOOR		○	○	⊗	○
ON	○		○	⊗	○

WITH SUNROOF:



WITHOUT SUNROOF:




Courtesy Lights


Replacement

NOTE: The bulb or lens alone can be replaced without having to remove the door trim panel.

1. Remove the door trim panel.
2. Remove the 2 screws and the retainer plate to remove the light from the door trim panel.



From No.12(15A)FUSE




To DOOR SWITCH

Door Switches



Test

1. Open the door.
2. Remove the screw and pull out the door switch.
3. Disconnect the 1-P connector from the switch.



4. There should be continuity between the positive terminal and base plate (ground) with the switch released (door opened). There should be no continuity with the switch pushed (door closed).