




Choke Cable (1.4 l Engine)

1. Check that choke control operates smoothly with no evidence of binding or sticking.
2. Set choke knob in the second detent position and check that the marks are aligned.



**ADJUSTING
MARKS**

3. If not aligned, loosen the locknut and adjust the adjusting nut, then retighten the locknut.