


Fuel Gauge

Gauge Test

NOTE: Refer to page 16-82 for wiring description of the fuel gauge circuit.

1. Fold down rear seat back, remove trunk carpet and board, then remove the maintenance access cover. (Care should be taken not to damage paint work if leaning in from rear hatch).
2. Disconnect the 2-P connector from the fuel gauge sending unit.



3. Connect the voltmeter positive probe to the B' (GRN/BLK) terminal and the negative probe to the A (BLK) terminal, then turn the ignition switch ON. There should be battery voltage.

- If there is battery voltage, go to step 4.
- If the voltage is not specified, check for:
 - Blown No. 1 (10A) fuse in the dash fuse box.
 - An open in the GRN, GRN/BLK or BLK wire.
 - Poor ground (G501).

4. Turn the ignition switch OFF. Attach a jumper wire between the A (BLK) and B (GRN/BLK) terminals.

Turn the ignition switch ON.

Check that the pointer of the fuel gauge starts moving toward "F" mark.

CAUTION: Turn the ignition switch OFF before the pointer reaches "F" mark on the gauge dial. Failure to turn the ignition switch OFF before the pointer reaches the "F" mark may cause damage to the fuel gauge.

NOTE: The fuel gauge is a bobbin (cross coil) type, hence the fuel level is continuously indicated even when the ignition switch is OFF, and the pointer moves more slowly than that of a bimetal type.


- If the pointer of the fuel gauge does not swing at all, replace the gauge.
- Inspect the fuel gauge sending unit if the gauge is OK.



Sending Unit Test / Replacement


WARNING Do not smoke while working on fuel system. Keep open flame away from work area.

1. Pull down the rear seat (see section 14), then remove the maintenance access cover.
2. Check that the ignition switch OFF, then disconnect the 2-P connector from the fuel gauge sending unit.
3. Remove the fuel gauge sending unit.



4. Measure the resistance between the A and B terminals at E (EMPTY), 1/2 (HALF FULL) and F (FULL) by moving the float.

Float Position	E	1/2	F
Resistance(Ω)	100-105	25.5-39.5	2-5



5. If unable to obtain the above readings, replace the fuel gauge sending unit.