



Horn

Circuit Diagram




Horn Test

1. Remove the front bumper.
 - Remove the right and left front turn signal lights.
 - Remove the 2 bumper mounting screws on each side at the corner edge of the bumper.
 - Remove the 2 lower bumper mounting bolts and the 4 bumper mounting bolts.
 - Lift and remove the bumper by sliding it forward.
 - Installation sequence is essentially the reverse order of removal.
2. Disconnect the wires from the horn.
3. Test the horn by connecting battery voltage to the A and B terminals. The horn should sound.
4. If the horn fails to sound, replace it.



Switch Test

1. Remove the steering wheel, then turn it over. (see, page 16-104)
2. Check for continuity between the contact ring and hub core on the steering wheel with the horn switch pressed. *There should be continuity.*



3. If there is no continuity, repair the horn switch.

