

Component Location



Index

Front Suspension:

STABILIZER BAR
Disassembly/Inspection,
page 12-9

FRONT LOWER ARM
Disassembly/Inspection,
page 12-9

RADIUS ROD
Disassembly/Inspection, page 12-9

FRONT DAMPER
• Removal, page 12-18
• Disassembly/Inspection, page 12-17
• Reassembly, page 12-19
• Installation, page 12-19

KNUCKLE/HUB
• Replacement, page 12-10
• Bearing Replacement,
page 12-11

Rear Suspension:

REAR UPPER ARM
Disassembly/Inspection,
page 12-22

REAR LOWER ARM
Disassembly Inspection,
page 12-22

COMPENSATOR ARM
Disassembly Inspection, page 12-22

TRAILING ARM
Disassembly Inspection, page 12-22

REAR DAMPER
• Removal 12-27
• Disassembly/Inspection,
page 12-28
• Reassembly
page 12-30
• Disposal, page 12-30
• Installation, page 12-31