




Fuel Filler Opener/Tailgate Opener

Replacement

RHD:

- To remove the opener cables, remove the following parts:
 - Right side door sill moldings, right and rear half of carpet.
 - Left quarter trim panel, trunk side panel and rear trim panel.
- Remove the screw and the release levers, then remove the opener cover. Remove the opener by removing the 2 bolts.
- Remove the fuel filler lid latch by turning it 90°.
- Remove the bolt, then remove the tailgate lock cylinder.
- Remove the latch cover and 3 bolts, then remove the tailgate latch.
- Disconnect the opener cable, connector and lock rod.


OPENER COVER



RELEASE LEVERS

OPENER CABLES

NOTE: Take care not to bend the cable.



STRIKER



OPENER

STOPPER

HARNESS PROTECTOR

OPENER CABLES

Clip Locations :




TAILGATE LATCH

TAILGATE LOCK CYLINDER

LOCK ROD

LATCH COVER




FUEL FILLER LID LATCH

MOUNTING BOLTS

FUEL FILLER LID

Before tightening the mounting bolts, adjust the filler lid fit and latch.



Use TORX® T40

GREASE

OPENER CABLE

STRIKER LINK

STRIKER ADJUSTMENT

Adjust the tailgate fit to the gate opening by moving the striker.

- To install, reverse the removal procedure. Check that the tailgate and fuel filler lid opener cables are routed and connected properly.