

# Turn Signal/Hazard Flasher System



## Component Location Index

### HAZARD SWITCH



Removal, page 16-120  
Test, page 16-120

### TURN SIGNAL INDICATOR LIGHTS

(in the gauge assembly)  
Gauge Assembly, page 16-85

### LIGHTING/TURN SIGNAL SWITCH

Test, page 16-104  
Replacement, page 16-105



### TURN SIGNAL/HAZARD RELAY

Input test, page 16-119

### DASH FUSE BOX

(Located under dash, driver side)