

Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



:Apply Automatic Transmission Fluid.



: Apply Power Steering Fluid.



:Apply or check vacuum.

①, ②, ③, :

①, ②, ③, :

Sequence for removal or installation.

Abbreviation

| | |
|----------|--------------------------------|
| 4D | 4-door Saloon |
| 5D | 5-door Saloon |
| A/C | Air Conditioner |
| A/T | Automatic Transmission |
| ATF | Automatic Transmission Fluid |
| B or BAT | Battery |
| CATA | Catalytic Converter |
| EACV | Electronic Air Control Valve |
| ECU | Electronic Control Unit |
| EX | Exhaust |
| GND | Ground |
| IG | Ignition |
| IN | Intake |
| INT | Intermittent |
| L | Left |
| LHD | Left Hand Drive |
| M/T | Manual Transmission |
| PCV | Positive Crankcase Ventilation |
| PGM-FI | Programmed Fuel-Injection |
| P/S | Power Steering |
| R | Right |
| RHD | Right Hand Drive |
| SW | Switch |
| SOL. V | Solenoid Valve |
| TDC | Top Dead Center |

| | |
|---|--------------------------|
| P | Parking |
| R | Reverse |
| N | Neutral |
| D | Drive Position (1st~4th) |
| D | Drive Position (1st~3rd) |
| 2 | 2nd speed |