

# Air Intake System

## System Troubleshooting Guide

NOTE: Across each row in the chart, the sub systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.

PAGE	SUB SYSTEM	THROTTLE CABLE	THROTTLE BODY	TANDEM CONTROL SYSTEM (1.5 l)	THROTTLE CONTROL SYSTEM
		155	157,160	162	169
	DIFFICULT TO START ENGINE WHEN COLD			①	
	WHEN COLD FAST IDLE OUT OF SPEC	③	②		①
	WHEN WARM RPM TOO HIGH	③	②		①
	WHEN WARM RPM TOO LOW		①		
	FREQUENT STALLING WHILE WARMING UP	③	②	①	
	LOSS OF POWER	③	②	①	