


Headlights


Adjustment

NOTE: Adjust the headlights to local requirements.



Replacement

1. Disconnect the 3-P connector from behind the unit.
2. Remove the front bumper and front position /side turn light.
3. Remove the screw and bolts and nut, then remove the unit.
4. Remove the nuts, then remove the garnish from the unit.
5. After installing the unit, adjust the headlights to local requirements.




Headlights

Bulb Replacement

CAUTION:

- Halogen headlights can become very hot in use; do not touch them or the attaching hardware immediately after they have been turned off.
- Do not try to replace or clean the headlights with the lights on.



License Plate Light

Bulb Replacement

1. Remove the 2 screws and pull out the light assembly from the lid.
2. Disconnect the 2-P connector from the housing.

