


Front Suspension

Lower Arm Busing Replacement


1. Remove the front wheels.
2. Remove the cotter pin from the knuckle and loosen the lower arm ball joint castle nut half the length of the joint threads.




3. Separate the ball joint and knuckle using a ball joint remover.

CAUTION: Avoid damaging the ball joint boot.

4. Remove the stabilizer link bolt from the lower arm.
5. Remove the radius rod bolt from the lower arm.
6. Remove the lower arm beam bolt then remove the lower arm.



7. Remove the lower arm bushing out of the lower arm from the direction indicated:



8. Drive the lower arm bushing from the direction indicated.

NOTE: Drive in the lower arm bushing so that their leading edges are flush with the lower arm.

