

# Electrical - Wire harness

Engine compartment - Diesel models


\* - COMPONENT NOT FITTED


498  
MAIN  
HARNESS

487 NOT  
USED



1  
BATTERY  
POSITIVE





86M 1752

## Diesel engine harness

E7 Earth point 7

C152 Coolant temperature sensor

C318 Engine compartment fusebox

C319 Engine compartment fusebox

C320 Cooling fan relay

C321 Glow plug timer

C322 Glow plug timer

C323 Glow plug timer

C324 Diagnostic plug

C325 Starter solenoid

C326 Reverse lamp switch

C327 Cooling fan

C328 Oil pressure switch

C329 Alternator

C330 Alternator


C331 Alternator

C332 Fuel cut-off solenoid

C333 Glow plugs

C430 High temperature sensor






86M 1766

## 1.4, 2.0 and Diesel main harness - passenger compartment

- |  |  |
|--|--|
| <b>E3</b> Earth point 3                  | <b>C51</b> Passenger compartment fusebox |
| <b>C14</b> LH side repeater              | <b>C52</b> Passenger compartment fusebox |
| <b>C17</b> Blower resistor               | <b>C53</b> Passenger compartment fusebox |
| <b>C18</b> Blower motor                  | <b>C54</b> Fascia harness connection     |
| <b>C21</b> Air conditioning harness      | <b>C56</b> Front wiper switch            |
| <b>C22</b> Ash tray illumination         | <b>C57</b> Rear wiper switch             |
| <b>C23</b> Cigar lighter                 | <b>C58</b> Lighting switch               |
| <b>C24</b> Cigar lighter illumination    | <b>C59</b> Indicator switch              |
| <b>C25</b> Heater controls illumination  | <b>C356</b> Inertia switch - not Diesel  |
| <b>C26</b> Blower switch                 | <b>C357</b> Radio/cassette to speakers   |
| <b>C32</b> Window lift relay             | <b>C358</b> Radio/cassette to speakers   |
| <b>C33</b> Relay module                  | <b>C360</b> CDL/Anti-theft alarm ECU - A |
| <b>C34</b> Relay module                  | <b>C361</b> CDL/Anti-theft alarm ECU - B |
| <b>C35</b> Throttle switch               | <b>C383</b> Driver's door harness        |
| <b>C38</b> Body harness                  | <b>C385</b> Catalyst overheat (Japan)    |
| <b>C39</b> RH side repeater              | <b>C388</b> Passenger's door harness     |
| <b>C42</b> Dim-Dip relay                 | <b>C390</b> Roof harness connector       |
| <b>C43</b> Front wiper relay             | <b>C403</b> Body harness                 |
| <b>C45</b> Passenger compartment fusebox | <b>C407</b> Front fog lamp relay         |
| <b>C47</b> Passenger compartment fusebox | <b>C408</b> Front fog lamp relay         |
| <b>C48</b> Ignition switch harness       | <b>C413</b> Air conditioning harness     |
| <b>C49</b> MFU                           | <b>C434</b> Aerial - Coupe/Cabriolet     |
| <b>C50</b> Stop lamp switch              |  |


# Electrical - Wire harness



## 1.4, 2.0 and Diesel fascia harness

**C103** Passenger compartment fusebox  
**C104** Main harness  
**C106** Mirror switch  
**C107** Panel dimmer switch  
**C109** Instrument pack  
**C110** Instrument pack  
**C112** Clock  
**C113** Glove box lamp  
**C114** Hazard switch  
**C115** Rear window demister switch

**C116** Rear fog lamp switch  
**C178** Ignition switch harness to passenger compartment fusebox  
**C181** Ignition switch harness to main harness  
**C375** Instrument pack  
**C399** Front fog lamp switch  
**C402** Instrument pack - Diesel/Catalyst overheat warning light



86M 1763

## 1.4, 2.0 and Diesel body harness - Rover 200

- |   |   |
|---|---|
| <b>E4</b> Earth point 4                     | <b>C88</b> Boot harness to taildoor sub-harness |
| <b>E5</b> Earth point 5                     | <b>C89</b> Boot harness to taildoor sub-harness |
| <b>C55</b> ABS diagnostics                  | <b>C92</b> Rear wiper relay                     |
| <b>C68</b> Body harness to main harness     | <b>C94</b> RH rear lamp                         |
| <b>C71</b> Passenger compartment fusebox    | <b>C96</b> Passenger front door                 |
| <b>C74</b> Drivers door switch              | <b>C97</b> LH rear door harness                 |
| <b>C75</b> RH rear door harness             | <b>C98</b> Hand brake switch                    |
| <b>C77</b> RH rear door switch(5 door only) | <b>C99</b> LH rear door switch(5 door only)     |
| <b>C78</b> RH rear speaker                  | <b>C100</b> LH rear speaker                     |
| <b>C79</b> RH rear speaker                  | <b>C101</b> LH rear speaker                     |
| <b>C80</b> Fuel tank unit                   | <b>C102</b> LH rear lamp                        |
| <b>C82</b> RH rear ABS sensor               | <b>C404</b> Body harness to main harness (ABS)  |
| <b>C83</b> LH rear ABS sensor               |   |
| <b>C85</b> Loadspace lamp                   |   |