





# Doors

## Molding Replacement


16. Stand next to the outside of the door, tilt the glass as shown, and pull it out through the window opening.



17. Remove the 4 mounting bolts and loosen the 2 motor bolts, then take out the regulator assembly through the lower hole in the door.




18. Remove the nut, then remove the center channel.





### Outer Molding:


1. Lower the window fully.
2. Remove the door mirror (pages 14-13, 14).
3. Remove the screw and detach the clips, then remove the outer molding prying up on the molding starting at the rear.



OUTER MOLDING



MOUNTING SCREW



OUTER MOLDING

(cont'd)

# Doors


## Molding Replacement (cont'd)

### Door Protector Molding:


4. Remove the door protector molding by removing the nut and detach the clips from the inside, or outside.

□ : Clip locations.


Front:



PLASTIC NUT




Rear:



FLAT TIP SCREW-DRIVER

SHOP TOWEL




5. Set the clips on to the moldings and protectors, then attaching the moldings and protectors.

## Assembly

Assemble the door in the reverse order of disassembly, and also:

1. Grease all the sliding surfaces of the window regulator where shown.



2. To adjust window fit in the door, raise the window as far up as possible and hold it against the door sash. Then, tighten the roller guide bolts.
3. Lower the window until there is a small gap between the door glass and the glass run channel.
4. Loosen the roller guide bolts and adjust the window glass so it parallel with the glass run channel.

Front:

