




Positive Crankcase Ventilation System

Inspection (1.5 l)

1. Check the crankcase ventilation hoses and connections for leaks and clogging.

BREATHER HOSE



2. At idle, make sure there is a clicking sound from the PCV valve when you lightly pinch the PCV hose with your fingers or pliers.


- If no clicking sound is heard, replace PCV valve and recheck.

Inspection (1.6 l)

1. Check the crankcase ventilation hoses and connections for leaks and clogging.


BREATHER HOSE

PCV HOSE



PCV VALVE

2. At idle, make sure there is a clicking sound from the PCV valve when the hose between PCV valve and intake manifold is lightly pinched with your fingers or pliers.



Gently pinch here

- If there is no clicking sound, check the PCV valve grommet for cracks or damage. If the grommet is OK, replace the PCV valve and recheck.