


12. Remove 2 screws securing air intake adaptor.
13. Remove air intake adaptor.



14. Remove bolt securing each radiator support bracket to bonnet platform.
15. Remove bolt securing oil cooler.
16. Remove bolt securing oil cooler to bonnet platform support.
17. Move radiator rearwards for access, remove oil cooler.

Refit

1. Reposition oil cooler, move radiator forwards.
2. Fit oil cooler securing bolts ,and tighten to 9 Nm.
3. Connect 2 hoses to oil cooler pipes; position and tighten clips.
4. Position 2 radiator support brackets; fit and tighten securing bolts to 9 Nm.
5. Position air intake adaptor; fit and tighten screws.
6. *Non - Turbo Models:* Position resonator bracket to battery tray; fit and tighten screws.
7. Fit battery tray; fit and tighten screws.
8. Position harness to battery tray; secure clips.
9. Fit air cleaner, see **FUEL SYSTEM - Repairs.**
10. Fit front bumper assembly, see **REPAIR MANUAL - BODY - Repairs.**
11. Fit battery into tray, fit clamp and tighten bolt; connect both battery leads.
12. Bleed power steering system, see **Adjustments.**

TORQUE SETTINGS

Oil cooler bolts	9 Nm
Radiator support bracket bolts.	9 Nm
Feed pipe to pump bolt	25 Nm
Pump to mounting bracket bolts and Torx screws	25 Nm
Pump pulley Allen screws	25 Nm