



Water Pump



Inspection


1. Remove the timing belt (SOHC, page 5-29), (DOHC, page 5-37).
2. Check the water pump pulley turns freely.
3. Check the signs of seal leakage.

NOTE: Small amount of "weeping" from the bleed hole is normal.



Replacement

1. Remove the timing belt (SOHC, page 5-29), (DOHC, page 5-37).
2. Remove the water pump by removing five bolts.



3. Install the water pump in the reverse order of removal.