



Fuses

Dash Fuse Box (LHD)

NOTE: Dash fuse box is located left side, under dash.




* : SPARE FUSE
< > : NOT USED






(RHD)

NOTE: Dash fuse box is located right side, under dash.





* : SPAER FUSE
● : Not used



Power Distribution

Circuit Identification





LHD : G301,G401
 RHD : G201,G401


(cont'd)

Power Distribution

Circuit Identification (cont'd)

KE model:


No.36(40A) FUSE
From page 16-172





Except KE model:

No.36(40A) FUSE
From page 16-172



(cont'd)

Power Distribution

Circuit Identification (cont'd)

