


Transmission Maintenance and Repair


Shift Fork Disassembly

1. Remove the shift fork shaft by removing the spring pins from the shift forks.


PIN DRIVER
3.0 mm
07744-0010200



PIN DRIVER
5.0 mm
07744-0010400




CAUTION: Do not lose the spring-loaded detent while disassembling the shift forks and shift fork shafts.



Shift Fork Reassembly

1. Insert the shift fork shaft into the shift forks and drive in the spring pins.

NOTE: Do not lose the steel balls and spring when reassembling.



1.0-1.5mm
(0.039-0.059in)

