



Front Door Disassembly


1. Remove the trim plate screw, then carefully remove the inside handle trim plate.



2. If applicable, remove the regulator handle by pulling the clip out with a wire hook.





3. Remove the screw and detach the clips, then remove the speaker cover.




4. Remove the door mirror cover panel (pages 14-13, 14).
5. Remove the screws and clips (See door panel release tool) attaching the door panel. Remove the door panel by pulling it upward and disconnect the power window and courtesy light wires.

NOTE: Remove the panel with as little bending as possible to avoid creasing or breaking it.




6. Remove the power window switch, if equipped, from the door panel by removing the screws.






7. Remove the screws, then remove the power door lock control unit, speaker and door panel bracket.
8. Carefully remove the plastic cover.




9. Remove the 3 screws, disconnect the latch rod, then remove the inside door handle.



10. Reconnect the window switch or use 12 V battery to operate the window regulator.

11. Raise the window fully.
12. Pull out the retainer clip, and take out the lock cylinder, then disconnect the lock rod.

NOTE: Use protective tape around the edge of the outside door handle to prevent scratching the paint.



13. Remove the mounting bolts for the outside door handle.
14. Pull the outside door handle out, and pry the joint off the handle with a flat tip screwdriver. Remove the handle from the rod.

(cont'd)


Front Door

Disassembly (cont'd)


15. Remove the screws and disconnect the wire.
16. Take the door latch off the door, then push the door latch and rod inside the door.

NOTE:


- Remove the lower bolt of the rear channel and slide the rear channel.
- Take care not to bend the latch rods.



17. Carefully lower the window until you can see its mounting bolts. Remove the bolts and pull the door glass out through the window slot.



18. Remove the 4 mounting bolts and loosen the 2 motor bolts, then take out the regulator assembly through the lower hole in the door.



19. Remove the glass run channel.
20. Remove the front and center channels by removing the bolts.

NOTE: Before installation, insert the glass run channel into the front and center channels.

