

Special Tools

Special Tools


Ref. No.	Tool Number	Description	Q'ty	Remarks
①	07HGK-0010100	Wheel Alignment Gauge Attachment	1	
②	07941-6920003	Ball Joint Remover	1	
③	07965-6340301	Hub Dis/Assembly Base	1	
④	07JAF-SH20110	Hub Dis/Assembly Pilot	1	
⑤	18G1584	Ball Joint Remover	1	
⑥	07965-6340341	Hub Dis/Assembly Base	1	
⑦	07GAF-SE00100	Hub Dis/Assembly Shaft	1	
⑧	07959-SA5000	Spring Compressor	1	
⑨	07965-6920201	Hub Dis/Assembly Base	1	
⑩	07947-SD90200	Attachment	1	
⑪	07GAF-SE00200	Hub Assembly Guide Attachment	1	
⑫	18G1600	Lower Arm Bush Front Remover/Replacer	1	
⑫-1	18G1600/1	Bush Base	1	Component tools
⑫-2	18G1600/2	Bush Driver	1	
⑬	18G1602	Lower Arm Bush Rear Remover/Replacer	1	
⑬-1	18G1602/1	Bush Base	1	Component tools
⑬-2	18G1602/3	Bush Driver	1	
⑬-3	18G1602/2	Bush Driver	1	
⑭	07GAE-SE00100	Spring Compressor	1	
⑮	07JAF-SH20310	Bush Driver	1	
⑯	07JAF-SH20340	Bush Base B	1	
⑰	07JAF-SH20330	Bush Base A	1	



①




②




③




④




⑤



⑥




⑦



⑧




⑨



⑩




⑪



⑫-1




⑫-2



⑬-1



⑬-2



⑬-3



⑭



⑮



⑯



⑰