


1st Accumulator

Disassembly/Inspection/Reassembly

NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner, and dry with compressed air. Blow out all passages.
- Coat all parts with ATF before reassembly.



Spring Specifications		Unit of length mm (in.)			
		Standard (New)			
No.	Spring	Wire Dia.	O.D.	Free Length	No. of Coils
①	1st accumulator one way ball spring	0.29(0.011)	4.0(0.157)	14.0(0.551)	13
②	1st accumulator spring A	2.34 x 2.90 (0.092 x 0.114)	21.5(0.846)	66.7(2.626)	10.2
③	1st accumulator spring B	2.8(0.110)	13.1(0.516)	40.0(1.575)	8.8