


Illustrated Index



NOTE : Whenever the transmission is removed, the release bearing sliding surface should be cleaned and greased (Molybdenum Disulfide).

