





## Rear Lower Arm Bushing Replacement

1. Remove the rear lower arm bushings out of the rear lower arm from the direction indicated.




2. Drive the rear lower arm bushings from the direction indicated.

NOTE: Drive in the rear lower arm bushings so that their leading edges are flush with the rear lower arm.



## Rear Damper Lower Bushing Replacement

1. Remove the rear damper lower bushing out of the rear lower arm from the direction indicated.



2. Drive the rear damper lower bushing from the direction indicated.

NOTE: Drive in the rear damper lower bushing so that their leading edges are flush with the rear lower arm.

