



Electrical Component Replacement



Climate Control Unit


Removal:

1. Remove the screws, then remove the front console (See Section 14).



NOTE: Be careful not to break the pawls on the front console.

2. Remove the screws (4), then pull out the climate control unit.
3. Disconnect the wire harness from the climate control unit before removing.




Installation:

Install the Climate control unit in the reverse order of removal.

Coolant Temperature Sensor

Removal:

1. Disconnect the 2P connector of the coolant temperature sensor from the heater assembly stay.
2. Remove the heater assembly clamp.
3. Pull out the coolant temperature sensor from the heater assembly as shown.



Installation:

Install the coolant temperature sensor in the reverse order of removal.