



# Cable Reel


## Removal

**⚠ WARNING** Store a removed airbag assembly with the pad surface up. If the airbag is improperly stored face down, accidental deployment could propel the unit with enough force to cause serious injury.

### CAUTION :


- Carefully inspect the airbag assembly before installing. Do not install an airbag assembly that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.
- Always keep the short connector on the airbag connector when the harness is disconnected.
- Do not disassemble or tamper with the airbag assembly.

1. Disconnect both the negative cable and positive cable from the battery.
2. Make sure the wheels are aligned straight forward.
3. Remove the instrument panel lower cover, then disconnect the wiper control unit connector.



4. Remove the steering wheel maintenance lid A, and disconnect the cable reel harness and airbag assembly 2-P connector. Connect the short connector to the airbag assembly (page 11-2).
5. Remove the upper and lower column covers.

### CABLE REEL HARNESS



6. Disconnect the connector between the cable reel and the SRS main harness, then remove the connector holder.
7. Remove maintenance lid B and cruise control set/resume switch cover (page 11-2).
8. Remove the airbag assembly from the steering wheel, then remove the steering wheel nut (page 11-5).


(cont'd)

# Cable Reel


## Removal (cont'd)

9. Disconnect the connectors from the horn and cruise control set/resume switches; remove the cable reel connector from its clips.

NOTE: To disconnect the cruise control 3-P connector, release both lock tabs, (A) and (B).




10. Remove the steering wheel from the column.
11. Remove the steering column upper and lower covers.
12. Remove the cable reel and cancel sleeve.



## Installation

### CAUTION :

- Before installing the steering wheel, the front wheels should be aligned straight forward.
  - Be sure to install the harness wires so that they are not pinched or interfering with other car parts.
  - After reassembly, confirm that the wheels are still straight ahead and that steering wheel spoke angle is correct. If minor spoke angle adjustment is necessary do so only by adjustment of the tierods, not by removing and re-positioning the steering wheel.
1. Align the cancel sleeve grooves with the cable reel projections.



2. Carefully install the cable reel and the cancel sleeve to the steering column shaft.

