



Transmission Housing

Removal/Installation

NOTE: Place two 70 x 70 x 450 mm (2.75 x 2.75 x 17.75 in) wood blocks under the clutch housing.

Removal

1. Remove the back-up light switch.
2. Remove the neutral switch.
3. Remove the ball spring setting screw, sealing washer, spring and detent ball.

Installation

1. Install the detent ball, spring, sealing washer and ball spring setting screw.
2. Install the neutral switch.
3. Install the back-up light switch.

