



Flow Chart — Climat Control System


NOTE: Use the digital circuit tester (07411—0020000)

No heater and A/C in either manual or AUTO modes.

Remove the climate control unit (page 15-89).

Turn the ignition switch ON.

Measure voltage between B-2 (+) terminal and B-13 (-) terminal.




Is there battery voltage?

NO

Repair open in WHT/YEL (B-2) wire between control unit and No.1 fuse.

YES

Measure voltage between B-1 (+) terminal and B-13 (-) terminal.



Is there battery voltage?

NO

Repair open in BLK/YEL (B-1) wire between control unit and No.10 fuse, or between No.10 fuse and ignition switch.

YES

Substitute a known-good control unit and recheck.