



# Positive Crankcase Ventilation System

## Inspection

1. Check the crankcase ventilation hoses and connections for leaks and clogging.



2. Remove the breather chamber cover and connect a vacuum pump to the PCV valve.



3. Pinch the hose as illustrated above, apply 400–500 mmHg (16–20 in.Hg) of vacuum then unpinch the hose and quickly check for a clicking sound on the PCV valve.

- If no clicking sound is heard, replace PCV valve and recheck.