

Control Unit


Replacement

1. Remove the rear seat back.
2. Remove the control unit attaching bolts, then remove the control unit.

CAUTION:

- If the control unit attaching bolts are removed, the control unit's memory is cleared.
- Handle the control unit with care.

6 x 1.0 mm
10 N·m (1.0 kg·m, 7 lb·ft)



Installation is the reverse order of removal.

NOTE: Check the **ALB** warning light function by turning the ignition switch ON.


Fail Safe Relays/ Motor Relay



Inspection

1. Check for continuity between terminals ③ and ④. There should be no continuity.
2. Connect a 12V battery across terminals ① and ②. There should be continuity between terminals ③ and ④.

Fail Safe Relays



Motor Relay

