

Carpet



Replacement

1. Remove:
 - Front seats.
 - Rear seat cushion.
 - Center console.
 - Right and left kick panels.
 - Door sill moldings.
 - Fuel lid opener.
 - Front seat belt lower anchor bolts.
 - Right and left quarter trim panel.
 - A/T control unit. (Automatic Transmission Only)
2. Pry out the clips at the rear edge and under the dashboard, peel off the tapes, pry off the retainers on each side and remove the carpet.

