



Front Bumper

Replacement

SRS wire harness is routed near the front bumper.

WARNING All SRS wire harness and connectors are colored Yellow. Do not use electrical test equipment on these circuit.

CAUTION: Be careful not to damage SRS wire harness when servicing the front bumper.

1. Remove the front side turn signal lights, then disconnect the wire harness.
 2. Remove the 7 lower bumper mounting bolts and the 4 bumper mounting bolts.
 3. Remove the bumper by sliding it forward.
 4. Remove the bumper, then disconnect the ambient sensor harness.
- If necessary:
5. Remove the bolts and nuts, then remove the front spoiler.
 6. Remove the bumper brackets by removing the bracket mounting bolts.

