





Overhaul

1. Drain the high pressure brake fluid from the power unit (see page 13-57).
2. Remove three 6 mm flange bolts, then remove the accumulator from the accumulator bracket.



3. Remove the banjo bolt.
4. Remove the 6 mm bolt and pressure switch.



5. Installation is the reverse order of removal.

Accumulator Disposal

WARNING The accumulator contains high pressure nitrogen gas, do not puncture expose to flame or attempt to disassemble the accumulator or it may explode; severe personal injury may result.

1. Secure the accumulator in a vice so that the relief plug points straight up.
2. Slowly turn the plug 3-1/2 turns and then wait 3 minutes for all pressure to escape.
3. Remove the plug completely and dispose of the accumulator unit.

