

Component Locations

LHD:

BRAKE LIGHT SWITCH
Troubleshooting page 9-10
Test, See Section 16

**COOLING FAN
CONTROL UNIT**
See Section 16

S4 SWITCH
Troubleshooting, page 9-9
Test, page 9-28

**SHIFT POSITION
CONSOLE SWITCH**
Troubleshooting, pages 9-15, 17
Test, See Section 16
Replacement, See Section 16

A/T CONTROL UNIT
Troubleshooting, page 9-6


**THROTTLE ANGLE
SENSOR**
Troubleshooting, page 9-13

**LOCK-UP CONTROL SOLENOID
VALVE ASSEMBLY**
Troubleshooting, pages 9-11, 12
Test, page 9-26
Replacement, page 9-26

A/T SPEED PULSER
Troubleshooting, page 9-21
Test, page 9-25
Removal/Inspection, page 9-25

**COOLANT TEMPERATURE
SENSOR**
Troubleshooting, page 9-22

**SHIFT CONTROL SOLENOID
VALVE ASSEMBLY**
Troubleshooting, pages 9-19, 20
Test, page 9-27
Replacement, page 9-27



RHD:

