





Coolant Temperature Sensor

Compare the resistance reading between terminals of the coolant temperature sensor with specifications shown in the following graph; should be within specification.




CAUTION: The sensor uses a thermistor which can be damaged if high current is applied to it during testing. Therefore, use a circuit tester with a measuring current of 1 mA or less.



Evaporator Temperature Sensor

Compare the resistance reading between terminals of the evaporator temperature sensor with specification shown in the following graph below: should be within specification.



CAUTION: The sensor uses a thermistor which can be damaged if high current is applied to it during testing. Therefore, use a circuit tester with a measuring current of 1 mA or less.

