




# Distributor Removal/Installation

## Removal

1. Remove the engine wire harness and connectors from the distributor.
2. Disconnect the spark plug wires and coil wire from the distributor cap.




3. Remove the distributor hold-down bolt, then remove the distributor from the cylinder head.

## Installation

1. Coat a new O-ring with engine oil then install it.
2. Slip the distributor into position.

NOTE: The lugs on the end of the distributor and its mating grooves in the camshaft end are both offset to eliminate the possibility of installing the distributor 180° out of time.



3. Install the hold-down bolt and tighten.
4. Connect the engine wire harness and connector to the distributor.
5. Connect the coil wire and the spark plug wires as shown.

