




Intermediate Shaft


Removal

1. Drain oil from the transmission.
2. Remove the three 8 mm bolts and one 10 mm bolt.




3. Lower the bearing support close to the steering gearbox and remove the intermediate shaft from the differential.

CAUTION: To prevent damage to the differential oil seal, hold the intermediate shaft horizontal until it is clear of the differential.




Disassembly

1. Remove the heat shield from the bearing support.



2. Remove the intermediate shaft outer seal.
3. Remove the 40 mm external circlip.



(cont'd)