




# Lock-Up Shift Valve Body

## Disassembly/Inspection/Reassembly

### NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner, and dry with compressed air. Blow out all passages.
- Check all valves for free movement, if any fail to slide freely, see Valve Body Repair.
- Coat all parts with ATF before reassembly.



### Spring Specifications

Unit of length: mm (in)

No.	Spring	Standard (New)			
		Wire Dia.	O.D.	Free Length	No. of Coils
①	Cooler relief valve spring	1.2 (0.047)	8.4 (0.331)	35.7 (1.406)	16.5
②	Lock-up shift spring	1.1 (0.043)	8.6 (0.339)	51.0 (2.008)	18.6