


A/T Speed Sensors

Replacement

1. Disconnect the connector.
2. Remove the A/C pipe holder bolt.
3. Remove the 6 mm bolt from the L. side cover and remove the speed sensor.

A/C PIPE
HOLDER BOLT



4. Replace the O-ring with a new one before reassembling the A/T speed sensor.