


Component Testing




In-car Temperature Sensor

The in-car temperature sensor assembly includes a small fan (aspirator fan) to draw air past the sensor.

Removal:

1. Remove the console (See Section 14).
2. Remove the mounting screws (3) and remove the in-car sensor assembly.



NOTE: Be careful not to damage the center console.

Installation:

Install the in-car temperature sensor assembly in the reverse order of removal.

Aspirator Fan

Connect battery positive to the YEL/BLK terminal of the connector and negative to the GRN terminal to check whether the fan motor runs.

