

Catalytic Converter

Replacement (C27A1 only)

1. Disconnect the rubber mounts from the catalytic converter support.
2. Remove the six nuts, then remove the catalytic converter from the exhaust system.
3. Remove the converter support and heat shield.
4. Install in the reverse order of removal.

CAUTION: Torque the converter flange nuts in the sequence shown.

CATALYTIC CONVERTER TORQUE SEQUENCE

